

Push Button

◀2s Run/Stop

3s Config

6s Reset

Config

1x Config LED = RailCom

2x Config LED = Auto. Invert

3x Config LED = Short Circuit

Push Button:

◀2s Option ON/OFF

3s Next Option