

Manual for the digital model railway beginners, Volume 2



Art. No.: 81396

€14,95

If you are driving and controlling digitally with the MULTIMAUS®, you already know the advances of the Roco-/FLEISCHMANN digital system. But how to enlarge your Starter Set, activate the wireless WiFi-MULTI-MAUS®, use tablet or smartphone for control or how to update your control units etc.